

+3V4 GND V B L H

CVMT  
CAWH  
CRX  
CTX  
GND  
3V3

CPU  
EXTENSION

GND

H L B A SCL  
SDA

RR  
TR  
RR  
TR

TERMINATION  
CAN

1000  
200  
1000  
200  
INV GND V2+  
INV GND V2C

GND 3V3 Rb 1b

A2n3  
B2n3  
V2  
GND  
RE  
TE  
TX  
RX

AD2  
JD2  
EVC  
GND

GND  
3V3  
SCL  
SDA  
TX  
RX  
MISO  
MOSI  
SCK  
N2S  
EARTH  
3V4

3V4  
EARTH  
N2S  
SCK  
MOSI  
MISO  
RX  
TX  
SDA  
SCL  
3V3  
GND

Mod4

CARRIER

Mod4

http://www.9962-29.99

GND  
3V3  
SCL  
SDA  
TX  
RX  
MISO  
MOSI  
SCK  
N2S  
EARTH  
3V4

3V4  
EARTH  
N2S  
SCK  
MOSI  
MISO  
RX  
TX  
SDA  
SCL  
3V3  
GND

Mod1

GND  
3V3  
SCL  
SDA  
TX  
RX  
MISO  
MOSI  
SCK  
N2S  
EARTH  
3V4

3V4  
EARTH  
N2S  
SCK  
MOSI  
MISO  
RX  
TX  
SDA  
SCL  
3V3  
GND

Mod3

GND  
3V3  
SCL  
SDA  
TX  
RX  
MISO  
MOSI  
SCK  
N2S  
EARTH  
3V4

3V3  
GND  
SCL  
SDA

3V4  
EARTH  
N2S  
SCK  
MOSI  
MISO  
RX  
TX  
SDA  
SCL  
3V3  
GND